

Wandebauventilatoren
Wall-mounted fans
Ventilateurs muraux




EN 20 ENR 20
EN 25 ENR 25
EN 31 ENR 31


Montage- und Betriebsanleitung
Mounting and Operating instructions
Instructions de montage et Mode d'emploi

D **GB** **F**







2A




2B




2C





2D




2E



2F



2G



9. Störungsbehebung



Lebensgefahr, Gerät steht unter Spannung!

GEFAHR Netzsicherung ausschalten!

Eine Störung kann z. B. durch erhöhte Fördermitteltemperaturen oder durch Blockieren des Ventilator-motors auftreten. Der Überlastungsschutz reagiert und der Ventilator schaltet aus.

- Bei einer Störung generell prüfen, ob die Netz-sicherung eingeschaltet ist. Eventuell den Ventila-tor von einem Fachmann auf korrekte Verkabe-lung prüfen lassen. Dazu unbedingt das Gerät all-polig vom Netz trennen.
- Ventilatormotor abkühlen lassen. Danach schat-tet der Ventilator automatisch wieder ein (Thermo-schalter ist selbsttätig rückstellend).
- Besteht die Störung weiterhin oder tritt diese wiederholt auf, die Netzsicherung ausschalten und eine Fachkraft hinzuziehen.

10. Entsorgung



Nicht in den Restmüll !

Das Gerät enthält teils wiederverwertbare Stoffe, teils Substanzen, die nicht in den Restmüll gelangen dürfen.

- Entsorgen Sie das Gerät nach Ablauf seiner Lebensdauer nach den in Ihrem Land geltenden Bestimmungen.

Wall-mounted fans

EN 20/ENR 20

EN 25/ENR 25

EN 31/ENR 31

1. Warning symbols in this manual



DANGER

Danger to life!

Non-observance can lead to death or serious bodily injuries.



CAUTION

Danger of injury/Property damage!

Non-observance can lead to minor or more serious bodily injuries or property damage.

2. Product information

Equipment overview, Figure 1



Spare parts are printed bold. With spare part orders, please quote the manual print number (see rear of envelope), the unit type and the corresponding item number.

1 Internal cover, complete

1.1 Protective bar

2 Terminal box complete

2.1 Sealing

2.2 Screws (3 pieces)

3 Connecting flange complete

4 Capacitor (ENR..)

5 Terminal block (EN.. 3-pin, ENR.. 4-pin)

6 Terminal block (3-pin)

7 Motor, complete

8 Impeller, complete

9 External shutters (= accessory)

Shutter "MK" (see figure)

Shutter "BK" or airstream-operated

external shutter "AS" (no picture)

9.1 Lamella

9.2 Gear motor

9.3 Connecting cable

9.4 Cable conduit

D Dowel (to be supplied by the customer)

S Fixing screw (to be supplied by the customer)

X Rating plate

Acknowledgements

© Maico Elektroapparate-Fabrik GmbH. This instruction is a translation of the German original operating instructions. We are not responsible for mistakes or printing errors and retain the right to make technical modifications without giving prior notice.

Product description

EN.. Fans for air extraction. Only in combination with external shutter "MK", "BK" or "AS".

ENR.. Fans with reversing mode for air extraction or ventilation. Only in combination with external shutter "MK" or "BK".

- EN.. and ENR.. fans are equipped with a thermal motor overload protection.
- Fans are switched on or off with a switching component that is to be provided by the customer, see wiring diagrams on page 16 to 19.

3. Technical Data

See rating plate.

4. Environmental conditions and operating limits

- Maximum permitted temperature of the air medium: +40°C
- Sufficient supply air intake must be ensured during operation with air-ventilated fireplaces. The maximum permitted pressure difference is 4 Pa.

5. Essential safety instructions

General safety instructions

- Read the safety instructions through carefully before commissioning.
- Keep the instructions.
- The device should not be used as a toy.
- Installation is only permitted when carried out by trained specialists.
- Electrical connections and repairs only permitted when carried out by trained specialists.
- With electrical and equipment installation the relevant regulations must be observed, particularly VDE 0100 with the corresponding parts. In rooms with baths or shower units, for example, this would be Part 701.
- Only connect the unit to a permanent electrical installation with a supply cable from 1.5...2.5 mm². This must be equipped with a mains isolation device with contact openings of at least 3 mm at each pole.

- The fan unit may only be operated using the voltage and frequency shown on the rating plate.
- Disconnect the unit completely from the power supply before removing the terminal box cover [2]. Also switch the mains fuse in the fuse box off.
- Modifications and alterations to the unit are not permitted and release MAICO from any guarantee obligations and liability.
- Never operate the fan without the internal cover and only when the external shutter is completely installed (protection against accidental contact with the impeller in accordance with EN 294).

Intended use

- EN.. and ENR.. fans for air extraction at offices, business and commercial premises, restaurants, doctors practices, etc.
- ENR.. fans, also for ventilation.
- For surface installation on walls, ceilings or pitched roofs.

Predictable misuses

The fan unit should not be used:

- close to flammable materials, liquids or gases.
- for the conveying of chemicals, aggressive gases or vapours.
- in explosive atmospheres.

Safe and correct practices during operation

- Danger of injury Do not insert any objects in the unit.
- Danger from self-turning impeller Do not get too close to the unit to avoid hair, clothing or jewellery being drawn into the unit.

6. Installation



CAUTION

Faulty operation and unit damage caused by a rubbing impeller with incorrect installation.

Install the connecting flange so that it is not under tension.

Make sure there is a level seating.



Important notes

- Wall thickness EN/ENR 20, EN/ENR 25 = **min. 105 mm**
Wall thickness EN/ENR 31 = **min. 130 mm**
- Make sure there is sufficient space to the wall or ceiling.
- In order to guarantee the degree of protection (IP value), the cable grommets [T...] must be drilled through/pierced correctly, i.e. with a circular hole that is somewhat smaller than the cable diameter.
- Never dismantle the external shutter.
- Only mount the external shutter on a level surface in order to guarantee the shutter function.

Wall mounting (Figures 2A and 2H)

- A** Mark and drill the holes for the plugs. Please refer to Figure 2A for the correct hole spacing for the connecting flange.
- B** Wall breakthrough, install power cable [L] (surface mounted „AP“ or recessed mounted „UP“) and wall sleeve „WH“, as required). Lay an empty ducting [9.4] with a slight incline towards the outside, for an electrically operated external shutter.
- C** Remove the internal cover [1]; the cover can be removed from the connecting flange [3] without using any tools. To do this, hold onto the connecting flange, open the internal cover [1] from the bottom (see ①) and move it upwards (see ②). Then remove the terminal box cover [2]. Remove the protective bar [1.1] first in the case of surface connection.
- D** Make a circular hole in the corresponding grommet [T...] in the connecting flange and feed the power cable through it.
- E** Fix the connecting flange [3] to the wall with suitable fixing material.
- F** Install the external shutter in line with the corresponding instructions. Feed the connection cable through the conduit [9.4] in the connecting flange and then through the black grommet [T5]

into the terminal box, in the case of an electrically operated external shutter. In order to stop moisture getting into the terminal box, make sure that the hole in the grommet is circular and slightly smaller than the diameter of the connection cable.

G Connect up the unit electrics, see wiring diagrams on Pages 16 to 19.



DANGER

Danger to life from electric shock!

Switch the mains fuse off.



CAUTION

Unit damage in the case of short-circuits!

Cut off and insulate PE conductor and individual cable cores that are not required.

Connect the fan to terminal block [5] and the external shutter to terminal block [6] by reference to the corresponding circuit diagram. The connections to terminal block [6] are not necessary in the case of „AS“ airstream operated external shutters.



The degree of protection (IP value) is only guaranteed if the cables are fed through correctly using the intended cable grommets [T1]...[T5].

- H** Put the terminal box cover [2] on and screw it into position, ensuring that the sealing [2.1] is correctly located.



Important: Tighten the 3 fixing screws of the terminal box cover with a torque of 1 Nm.

Locate the internal housing [1] into position. To do this, hang the internal housing on the top of the connecting flange [3] and then click it down into position. Don't bend or distort it.

- **Switch the mains fuse on. Carry out a function test.**

Ceiling installation (no picture)

- Carry out the ceiling installation as described in the wall mounting section.




CAUTION

Danger of short-circuits and unit damage by a build-up of condensation in the fan housing.

Thermally insulate the ventilation ducts correctly.

- Drill through the internal cover [1] at position [B] carefully and with a suitable drill bit. The hole prevents the build up of damp and bacteria in the fan housing.



i Observe the dimensioned drawing. Drill hole [B] with a diameter of 3.5 mm, 20 mm to the left of the housing marking [M].

- Secure the internal cover [1] with the supplied screw at marking [M]. 3 x 10 mm screw is secured in the internal cover with sticky tape.

7. Maintenance

The unit is maintenance-free.

8. Cleaning



Danger to life! Unit is powered up.

DANGER Switch the mains fuse off. Do not flood the unit with liquid.

- Remove the internal cover [1] as shown in Figure 2C. The cover can be removed from the connecting flange without using any tools.

Under no circumstances should the internal cover be pulled from the top or by using the internal grille.

- Clean the internal part with a dry cloth or use a vacuum cleaner if required. Open the flaps upwards to clean the external shutter.



Never use any cleaning agents that may be injurious to health or that are abrasive or easily inflammable.

- Finally, position the internal cover [1] as shown in figure 2H.



Do not clean the internal cover in a dishwasher.

9. Fault rectification



DANGER

Danger to life! Unit is powered up.

Switch the mains fuse off.

A malfunction can occur, for example, if the airstream temperatures are too high or if the fan motor is blocked. The overload protection device reacts and switches the fan off.

- If the fan fails to operate, always check whether mains power is switched on. If necessary, have the fan's wiring checked by an electrician. Before starting such work, make sure the fan is completely disconnected from the mains.
- Allow the fan motor to cool down and then the fan will switch back on automatically (the thermal switch resets automatically).
- If the unit fails to restart or if it breaks down again, remove the power and call on the services of a specialist.

10. Disposal




Not in domestic waste.

The unit contains in part material that can be recycled and in part substances that should not end up as domestic waste.

- Dispose of the unit once it has reached the end of its working life according to the regulations valid where you are.


Schaltbilder / Wiring diagrams / Schémas de connexions

- EN 20**
EN 25
EN 31
 – mit Ein/Aus-Schalter
 – with On/Off switch
 – avec interrupteur
 Marche/Arrêt



- S1 Ein/Aus über:
 – Ausschalter
 – Thermostat TH..
 – Hygroskop HY5
 – Luftqualitätsregler EAQ
 * Leitung nur für Klappe MK..
- S1 On/Off via:
 – switch
 – TH.. thermostat
 – HY5 hygroskop
 – EAQ air quality controller
 * Cable only for MK.. shutter
- S1 Marche/Arrêt par:
 – interrupteur
 – thermostat TH
 – hydrostat HY5
 – régulateur de la qualité par l'air EAQ..
 * Conducteur uniquement pour trappe MK

- EN 20**
EN 25
EN 31
 – mit 5-Stufentransformator TRE..
 – with TRE... 5-step transformer
 – avec transformateur à 5 plots
 TRE...




- TRE 5-Stufentransformator (Ein/Aus, 5 Drehzahlen)
 * Leitung nur für Klappe MK..
- TRE 5-step transformer (On/Off, 5 speeds)
 * Cable only for MK.. shutter
- TRE Transformateur à 5 plots (Marche / Arrêt, 5 vitesses)
 * Conducteur uniquement pour trappe MK..

ENR 20

ENR 25

ENR 31

- mit Ein/Aus-Schalter und Wechselschalter
- with On/Off switch and reversing switch
- avec interrupteur Marche/Arrêt et commutateur inverseur




- S1 Ein/Aus
- S2 Umschaltung
- Entlüftung/Belüftung
- Klemme 5: Entlüftung
- Klemme 6: Belüftung
- * Leitung nur für Klappe MK..
- S1 On/Off
- S2 Switching: air extraction/ventilation
- Terminal 5: air extraction
- Terminal 6: ventilation
- * Cable only for MK.. shutter
- S1 Marche/Arrêt
- S2 Commutation extraction d'air/aération
- Borne 5: extraction d'air
- Borne 6: aération
- * Conducteur uniquement pour trappe MK.

ENR 20

ENR 25

ENR 31


- mit Stufen-Wendeschalter FS6, FS7
- with FS6, FS7 step/reversing switch
- avec commutateur inverseur à plots FS6, FS7



- FS6 Stufenschalter (Entlüftung/Belüftung, 2 Drehzahlen)
- FS7 Wendeschalter (Entlüftung/Belüftung)
- * Leitung nur für Klappe MK..
- FS6 Step switch (air extraction/ventilation, 2 speeds)
- FS7 Reversing switch (air extraction - ventilation)
- * Cable only for MK.. shutter
- FS6 Commutateur à plots (extraction/aération, 2 vitesses)
- FS7 Commutateur inverseur (extraction/aération)
- * Conducteur uniquement pour trappe MK..

ENR 20
ENR 25
ENR 31


- mit Wendeschalter W/WU1
- with W/WU1 reversing switch
- avec commutateur inverseur W/WU1



- W/WU1 Wendeschalter mit Ein/Aus
- * Leitung nur für Klappe MK..
- W/WU1 Reversing switch with On/Off
- * Cable only for MK.. shutter
- W/WU1 Commutateur inverseur avec Marche/Arrêt
- * Conducteur uniquement pour trappe MK..

ENR 20
ENR 25
ENR 31

- mit 5-Stufentransformator TRE... und Wendeschalter W1/WU1
- with TRE... 5-step transformer and W1/WU1 reversing switch
- avec transformateur à 5 plots TRE... et commutateur inverseur W1/WU1




- TRE 5-Stufentransformator (Ein/Aus, 5 Drehzahlen)
- W/WU1 Wendeschalter (Entlüftung - 0 - Belüftung)
- * Leitung nur für Klappe MK..
- TRE 5-step transformer (On/Off, 5 speeds)
- W/WU1 Reversing switch (air extraction - 0 - ventilation)
- * Cable only for MK.. shutter
- TRE Transformateur à 5 plots (Marche / Arrêt, 5 vitesses)
- W/WU1 Commutateur inverseur (extraction - 0 - aération)
- * Conducteur uniquement pour trappe MK..

ENR 20

ENR 25

ENR 31

- mit 5-Stufentransformator TRE... und Wechselschalter
- with TRE... 5-step transformer and reversing switch
- avec transformateur à 5 plots TRE... et commutateur inverseur




- TRE 5-Stufentransformator (Ein/Aus, 5 Drehzahlen)
- S1 Wechselschalter (Entlüftung – Belüftung)
- * Leitung nur für Klappe MK..
- TRE 5-step transformer (On/Off, 5 speeds)
- S1 Reversing switch (air extraction – ventilation)
- * Cable only for MK.. shutter
- TRE Transformateur à 5 plots (Marche / Arrêt, 5 vitesses)
- S1 Commutateur inverseur (extraction – aération)
- * Conducteur uniquement pour trappe MK..

ENR 20

ENR 25

ENR 31

- mit 5-Stufentransformator TRE...S und 5-Stufenschalter ESS 20
- with TRE...S 5-step transformer and ESS 20 5-step switch
- avec transformateur à 5 plots TRE...S et commutateur à 5 plots ESS 20



- TRE...S 5-Stufentransformator (Schaltschrank-Einbau)
- ESS 20 5-Stufenschalter (Ein/Aus, 5 Drehzahlen)
- S1 Wechselschalter (Entlüftung – Belüftung)
- * Leitung nur für Klappe MK..
- TRE...S 5-step transformer (switch cabinet installation)
- ESS 20 5-step switch (On/Off, 5 speeds)
- S1 Reversing switch (air extraction/ventilation)
- * Cable only for MK.. shutter
- TRE...S Transformateur à 5 plots (intégration armoire électrique)
- ESS 20 Commutateur à 5 plots (Marche/Arrêt, 5 vitesses)
- S1 Commutateur inverseur (extraction – aération)
- * Conducteur uniquement pour trappe MK..