


Fensterventilatoren
Window Fans
Ventilateurs de fenêtre




EV 31
EVR 31
EVH 31

Montage- und Betriebsanleitung
Mounting and operating instructions
Instructions de montage et mode d'emploi



A



EV 31, EVR 31 and EVH 31

Scope of delivery

- Internal housing, complete
- Connecting flange
- External grille
- Assembly instruction
- Accessories

Table of contents

Scope of delivery.....	10
1. Warning symbols.....	10
2. Product information	10
Equipment overview.....	10
Product description.....	11
3. Technical Data	11
Dimensions and weight	11
Rated voltage and frequency.....	11
4. Environmental conditions and operating limits.....	11
5. Essential safety instructions	11
General safety instructions.....	11
Intended use	11
Predictable misuses	11
Safe and correct practices during operation	12
6. Installation preparation	12
Installation in windows.....	12
Installation in walls and wooden panels	12
Dismantling internal housing with connecting flange	12
7. Installation.....	13
Installation in windows.....	13
Installation in walls and wooden panels	13
Electrical connection	14
Internal housing installation	14
8. Operation	15
9. Maintenance.....	15
With fans in swivel windows	15
10. Cleaning.....	15
11. Dismantling ventilation unit.....	15
12. Fault rectification	16
13. Spare parts.....	16
14. Disposal	16
Wiring diagram	25

1. Warning symbols



DANGER

Danger to life

Non-observance can lead to death or serious bodily injuries.



WARNING

Danger of injury

Non-observance can lead to serious bodily injuries



CAUTION

Danger of injury

Non-observance can lead to minor or more serious bodily injuries.

NOTICE

Property damage.

Non-observance can lead to damage to property.

2. Product information

Equipment overview, Figure A

- 1 Internal housing, complete
 - EV 31, EVR 31: With electrical internal shutter
 - EVH 31: Internal shutter with pull-cord for manual operation
- 2 Screw
- 3 Connecting flange
 - 3.1 Locking hook
- 4 Window pane
- 5 Cable grommet
- 6 Capacitor
- 7 Window pane ring
- 8 External grille
 - 8.1 Housing dome
- 9 Connection terminal socket
- 10 Window pane ring
- 11 Ball
- 12 Connection terminal plug
- 13 Catch
- 14 Impeller
- 15 Motor
- 16 EVH 31: Pull-cord
- X Rating plate

Imprint: © Maico Elektroapparate-Fabrik GmbH. E & OE. We reserve the right to make technical modifications.

Product description

Wiring diagram, see page 25

- **EV 31** with electrical internal shutter. For air extraction. Speed controllable. On/off with light switch or separate switch (all to be supplied by customer). The fan unit switches on/off immediately when the switch is operated. Internal shutter opens/closes automatically.
- **EV 31** with electrical internal shutter. For ventilation or air extraction. Speed controllable. On/off with light switch or separate switch (all to be supplied by customer). The fan unit switches on/off immediately when the switch is operated. The internal shutter opens/closes automatically.
- **EVH 31** with internal shutter and 1 metre long pull-cord for manual operation. For air extraction. The fan unit switches on/off by pulling the pull-cord. The internal shutter opens/closes automatically.

3. Technical Data

- See rating plate.

Dimensions and weight

- Internal housing: 410 x 410 x 130 mm
- External grille: 410 x 410 x 23 mm
- Window cut-out: 360 mm diameter
- EV 31, EVR 31: 7.6 kg
- EVH 31: 6.4 kg

Rated voltage and frequency

- See rating plate.

4. Environmental conditions and operating limits

- Maximum permitted temperature of the air medium: +40 °C
- Sufficient supply air intake must be ensured during **operation with air-ventilated fireplaces**. The maximum permitted pressure difference per living unit is 4 Pa.

5. Essential safety instructions

General safety instructions

- Read the safety instructions through carefully before commissioning.
- Keep the instructions.
- The device must not be used as a toy.
- Installation is only permitted when carried out by trained specialists.
- Electrical connections and repairs only permitted when carried out by electricians.
- Only connect the unit to a permanent electrical installation.
Permitted cable cross section: 0.75 mm² to 1.5 mm².
Use suitable, flexible connecting cable if the unit is installed in a swivel window. Mains isolation device required with contact openings of at least 3 mm at each pole.
- The fan unit may only be operated using the voltage and frequency shown on the rating plate.
- Do not make any modifications to the fan unit.
- Only operate the fan unit when it is completely installed. Never operate without an external grille.
- Operation is only permitted when the internal housing is in place and locked shut.

Intended use

- EV 31 and EVH 31: For **air extraction** at offices, business and commercial premises, restaurants, manufacturing and workplaces, doctors practices, etc.
- EVR 31: For **ventilation or air extraction** of the above-mentioned premises.
- For vertical installation in windows or thin walls.
- In hinged double-glazed windows, composite windows and glass brick walls, only with the suitable Maico accessory ZD or ZG.

Predictable misuses

Maico is not liable for damages caused by use contrary to the intended purpose. **Under no circumstances should the unit be used:**

- on sloping walls, pitched roofs or ceilings.

- close to flammable materials, liquids or gasses.
- in explosive atmospheres.

Safe and correct practices during operation

- **Danger of injury** Do not insert any objects in the unit.
- **Danger from self-turning impeller** Do not get too close to the unit to avoid hair, clothing or jewellery being drawn into the unit.
- The unit is not intended to be used by people whose physical, sensory or mental capabilities are not sufficient for them to understand and put into practice the safety information provided in these instructions. This restriction also applies to children. The unit may however be safely used by such persons if they are supervised by someone responsible for their safety or if they are instructed in a suitable way.

6. Installation preparation

Installation in windows



WARNING

Danger of cuts caused by sharp glass edges and glass breakage. Damage to the window pane from material stress.

- If necessary, extract the window pane and putty it back in place without stress.

NOTICE

Functional impairment and unit damage if installed on an uneven substrate.

- Make sure there is a level seating in the area of the window pane rings [7] and [10].




CAUTION

Danger of short-circuits with sloping installation position through the build-up of condensation inside the housing.

- Only install the unit vertically, with the cable feed from above.

- Decide on the installation position. Maintain sufficient distance (min. 50 mm) from the window frame or wall/ceiling. Allow enough space for a correct cable feed and the opening area of the window.
- Get **an expert** to make the window cut-out – diameter 360 mm.



- Lay the power cable.

Installation in walls and wooden panels

- Make the same preparations for the installation in walls and wooden panels as described under Installation in windows.

Dismantling internal housing with connecting flange, see Figure A, bottom left.

- Loosen both catches [13] with a screwdriver.
- Hold on to the internal housing, slightly angle the connecting flange and disconnect it from both locking hooks [3.1].
- Pull the connection terminal plug [12] off.
- Remove the testing cables from the connection terminal socket [9]. These are no longer required.

7. Installation


Installation in windows

NOTICE Faulty operation and unit damage caused by a rubbing impeller [14] with incorrect installation.

- Do not install the internal housing twisted or crimped.

i The internal housing [1] should only be installed indoors. Outdoor installation of the internal housing [1] is not permitted.

- Press the external grille [8] and the connecting flange against the window pane from outside and inside respectively.



- Line the external grille and connecting flange up horizontally and bolt them together with the M5 x 25 bolts supplied [2]. The ball [11] can be used to help if unlatched first.



Danger of injury through glass breakage if the bolts are over-tightened.

- Tighten the bolts carefully and do not over-tighten them.
- Make sure you have enough sealant, e.g. silicone in the case of special, e.g. corrugated glass.




Notes

- Make sure there are no leaks at the window pane rings [7] and [10].
- In the case of a window pane that is > 8 mm thick, replace the supplied bolts [2] with other suitable ones, of your own choosing.

Installation in walls and wooden panels

- Drill through the 4 housing domes [8.1] on the external grille – diameter 5.5 mm.
- Install the external grille and connecting flange as described before.
- Mark additional drill holes on the wall through the housing domes [8.1].
- Loosen the mountings a little and turn the external grille with the connecting flange in the wall breakthrough by approx. 45°.
- Drill through the wall (4 holes).



- Line up the external grille with the connecting flange again and bolt them together as described before.
- Additionally, the external grille is fixed to the connecting flange through the 4 drilled holes. Make sure that suitable bolts and nuts are available on site.

Electrical connection



DANGER

Danger to life from electric shock

- Switch the mains fuse off.



CAUTION

Unit damage in the case of short-circuits


- Cut off and insulate any unnecessary cable cores.



CAUTION

Danger of short-circuits through incorrect feeding of the power cable into the housing.

- Feed the power cable professionally through the cable grommet and make sure there is tension relief. See printed cable run.



- Locate both cable grommets [5] in the connecting flange.
- Feed the power cable through the open cable grommet.
- Connect the power cable to the connection terminal socket [9] as shown in the wiring diagram on Page 25.

Internal housing installation

see also Figure A, bottom right



CAUTION


Danger of short-circuits and unit damage with wrong polarity

- Make sure the polarity is correct, see labels A and B.

NOTICE

Damage to the contact holder caused by tearing or pulling on the plug cable

- Always hold the internal housing near the connecting flange to avoid pulling tension at plug connection.



- Plug the connection terminal plug [12] on to the connection terminal socket [9].
- Push the internal housing parallel onto the connecting flange as shown bottom right in Figure A.



The internal housing must clip into the upper locking hooks [3.1]. Don't trap the cables.

- Close both catches [13] with a screwdriver.
- Switch the mains fuse on.
- Carry out a function test.

8. Operation

EV 31

- Switch the unit on using the switch, e.g. speed controller ST...
The internal shutter opens automatically.
The fan unit runs and extracts air from the room.
- Switch the unit off with the switch.
The internal shutter closes.
The fan unit switches off.


EVR 31

- Switch the unit on using the switch, e.g. reversing switch STW...
The internal shutter opens automatically.
The fan unit runs and ventilates or extracts air from the room.
- Switch the unit off with the switch.
The internal shutter closes.
The fan unit switches off.

EVH 31

NOTICE Unit damage by jerky pulling at the pull-cord

- Don't pull the pull-cord in a jerky way.



- Switch the unit on by pulling the pull-cord angled towards the front.
The internal shutter opens mechanically.
The fan unit runs and extracts air from the room.
- Switch the unit off by pulling the pull-cord angled towards the window or wall and then return it to its base position. .
The internal shutter closes mechanically.
The fan unit switches off.

9. Maintenance

The unit is maintenance-free.

With fans in swivel windows

- Check the connection cable regularly for signs of damage at the transfer point from the window sash to the window frame.
- If the cable is damaged, have it replaced by a trained electrician.

10. Cleaning



DANGER

Danger to life. Unit is powered up

- Switch the mains fuse off.
- **Do not** remove the internal housing for cleaning.
- Do not flood the unit with liquid.
- Clean the unit with a damp cloth.

11. Dismantling ventilation unit

see also Figure A, bottom left



DANGER

Danger to life from electric shock

- Switch the mains fuse off.
- Open both catches [13].
- Swing the internal housing up slightly and remove it.
- Disconnect the electrics.
- Remove the connecting flange and external grille.

12. Fault rectification

- **Call on the services of a trained electrician** any time there is a fault.
- Repairs should only be carried out by a trained electrician.



DANGER

Danger to life. Unit is powered up

- Switch the mains fuse off.

Fault	Countermeasure
Unit doesn't run. Thermal overload protection of the motor switches unit off and back on again after cooling down.	Localise the cause of the fault and rectify it.

Tab. 1: Fault rectification

13. Spare parts

- i** When ordering spare parts, always quote the print number 0185.0853.0007 from these instructions, the rating plate number "X" and the corresponding item number.

Item, Page 2 Figure A	Designation
1	Internal housing, complete – EV 31, EVR 31 – EVH 31
8	External grille VM
13	Catch
15	VM motor gear – EV 31, EVR 31

Tab. 2: Spare parts

14. Disposal


- i** **Not in domestic waste.** The unit contains in part material that can be recycled and in part substances that should not end up as domestic waste.

- Dispose of the unit once it has reached the end of its working life according to the regulations valid where you are.

Schaltbilder / Wiring diagram / Schémas de branchement

EV 31


mit Drehzahlsteller ST/STU1, ST/STU/STS2,5
with speed controller ST/STU1, ST/STU/STS2,5
avec régulateur de vitesse ST/STU1, ST/STU/STS2,5



ST/STU1 Drehzahlsteller max. 1 A
Speed controller max. 1 A
Régulateur de vitesse 1 A

ST/STU/STS2,5 Drehzahlsteller max. 2,5 A
Speed controller max. 2,5 A
Régulateur de vitesse 2,5 A


EV 31



S1 Ein/Aus
On/Off
Marche/Arrêt

EVR 31


mit Steuergerät STW1, FS7
with control unit STW1, FS7
avec unité de commande STW1, FS7



STW1 Drehzahlsteller mit Wendschalter
STW1 Speed controller with reversing switch
STW1 Régulateur de vitesse avec inverseur

FS7 Wendschalter (Eni- und Belüftung)
FS7 Reversing switch (Air extraction and ventilation)
FS7 Inverseur (Evacuation et insufflation)

EVR 31



S1 Ein/Aus
S1 On/Off
S1 Marche/Arrêt

S2 Umschaltung: Ent- oder Belüftung
S2 Switching: Air extraction or ventilation
S2 Inversion: Evacuation ou insufflation

EVH 31

