



RPA

Passar fläktmodell

Typ	CMA CMAT	CMC	CB	CBP	CAST CAS	CMRT	CA	CAM	CMP	CTMP TCMP	CMT	TCR TCRR
RPA-10	-	-	-	-	-	-	-	-	38	-	-	-
RPA-11	218	-	-	-	-	-	-	-	-	-	-	-
RPA-13	-	-	-	-	-	-	234	-	-	-	-	-
RPA-15	325/426	-	-	-	242	-	142	-	512	-	-	-
RPA-17	527	-	-	-	248	-	148	-	514	-	-	-
RPA-18	528	-	-	-	254	-	154	-	-	-	-	-
RPA-20	531	-	-	-	260	-	-	-	616	-	-	-
RPA-23	-	628/630	-	-	680	-	160/166/172	540/545	718	-	922	-
RPS-25	540/545	835/840	820	-	790	-	-	-	620/820	820	1025	-
RPA-28	-	-	-	-	463/467	-	-	550/752	922	922	1128	-
RPA-31	-	-	1428	-	571/640/645/650/980/1080	-	-	760	1025	1025	1231	-
RPA-35	-	-	-	-	852/990/1090	-	-	-	1128	1128	1435/1640	-
RPA-38	-	-	1733	-	-	1650	-	880	1231	1231	-	1135
RPA-42	-	-	-	-	856	1856	-	-	1435	1435	1845	1135
RPA-44	-	-	-	-	1250/A	-	-	-	-	-	-	-
RPA-47	-	-	2240	-	863/971	2271/2063	-	-	1640	1640	2050	1240 1240
RPA-48	-	-	-	-	1456/A	-	-	-	-	-	-	-
RPA-52	-	-	-	1445	-	-	-	-	1845	1845	-	1445 1445
RPA-60	-	-	-	1650	-	-	-	-	2050	2050	-	1650 1650
RPA-65	-	-	-	-	1663/A	-	-	-	-	-	-	-
RPA-66	-	-	-	1856	-	-	-	-	-	-	-	1856 1856
RPA-73	-	-	-	-	1671/A - 2071/A	-	-	-	-	-	-	2271 2271
RPA-81	-	-	-	-	-	-	-	-	-	-	-	2380 -
RPA-88	-	-	-	-	-	-	-	-	-	-	-	2590 -


Passar fläktmodell

Typ	HEPT	HCT	HGT	HPX	THT
RT-25	-	25	-	-	-
RT-31/B	-	31	-	-	-
RT-31/B	31	-	-	-	-
RT-35	35	35	-	35	-
RT-40	40	40	-	-	40
RT-45	45	45	-	45	45
RT-50	50	50	-	50	50
RT-56	56	56	-	56	56
RT-63	63	63	-	63	63
RT-71	-	71	-	71	71
RT-80-RT-90	-	80	-	80	80
RT-100	-	100	-	100	100
RT-125	-	-	125	-	125
RT-125/CC	-	-	125	-	125

RT



RI



Passar fläktmodell

Typ	HEP	HCD	HC	HRE	HCH	HCDF/HDF
RI-20	-	20	-	-	-	-
RI-25/E	-	-	-	25	-	-
RI-25	25	25	25	-	-	25
RI-31/E	-	-	-	31	-	-
RI-31	31	30	31	-	-	31
RI-35/E	-	-	-	35	-	-
RI-35/B	-	-	-	-	35	-
RI-35/C	35	35	35	-	-	35
RI-40	40	40	40	-	40	40
RI-45	45	-	45	-	45	45
RI-50	50	-	50	-	-	50
RI-56	56	-	56	-	56	56
RI-63	63	-	63	-	63	-/63
RI-71	-	-	71	-	71	-/71
RI-80	-	-	80	-	80	-/80
RI-90	-	-	90	-	90	-/90
RI-100	-	-	100	-	100	-


R



Passar fläktmodell

Typ	HC	HCH/HDF			
R-35/B	-	35			
R-40	-	40			
R-45	-	45			
R-56	-	56-4T/M-0,75	56-4T-1	56-6T/M-0,33	56-6T-0,5 56-6T-0,75
R-56-1,5	-	56-4T-1,5 56-4T-2			
R-63-0,5	-	63-4T-1 63-6T/M-0,5 63-6T-0,75			
R-63-1,5	-	63-4T-1,5 63-4T-2 63-6T-1			
R-63-4	-	63-4T-3 63-4T-4			
R-71	-	71-4T-1,5	71-4T-2	71-6T/M-0,75	71-6T-1 71-6T-1,5
R-71/C	71	-			
R-71-3	-	71-4T-3 71-4T-4			
R-80	-	80-6T-1	80-6T-1,5	80-8T-0,5	80-8T-0,75
R-80/C	80	-			
R-80-5,5	-	80-4T-3	80-4T-4	80-4T-5,5	80-6T-2 80-6T-3 80-8T-1
R-90	-	90-4T-4	90-4T-5,5	90-6T-2	90-6T-3 90-8T-1 90-8T-1,5 90-8T-2
R-90/C	90	-			
R-90-7,5	-	90-4T-7,5	90-4T-10	90-6T-4	90-8T-3
R-100	-	100-6T-3 100-8T-1,5 100-8T-2			
R-100/C	100	-			
R-100-7,5/C	100-4T/H	-			
R-100-10	-	100-4T-7,5	100-4T-10	100-6T-4	100-6T-5,5 100-8T-1,5 100-8T-2
R-100-20	-	100-4T-15 100-4T-20			

AGO



Typ	För fläkt typer
AGO 100	CA100/VKA100
AGO 125	CA125/VKA125
AGO 160	CA160/VKA160
AGO 200	CA200/VKA200
AGO 250	CA250/VKA250
AGO 315	CA315/VKA315
AGO 355	VKA355
AGO 400	Kanal Ø400
AGO 450	Kanal Ø450
AGO 500	Kanal Ø500

Ventilation

Axialfläktar

Radialfläktar

Punktstug

EX-Fläktar

Rök-/Brandgas

Sidokanal

Tillbehör